Introduce:

Item name LED GUN I Pro DMX control: 4 CHANNEL.

LED quantity: R48, G48, B48, W 48, Y32

Power consumption: 25W Dimension: 300x230x230mm

Power in: AC110V.-240V. 50Hz/60Hz

Unit weight: 2.5kgs

Item features:

This is the newest series of DMX LED FLOWER EFFECT which with pcs of super bright 10mm RGB LED as lamp sources. It can run with the digita 1 display for built-in programs, sound active function and sensitivity control, master / slave mode and DMX control.

LED FLOWER EFFECT is the best applications for disc o club, bar and home party. The best strong beam-out effect can be fulfilled by using with the fog machines.

Operation instructions (LED Display specifications):

Addr

When the fixture connects with the standard DMX controller, press MODE button into this window, then you can set the DMX address from 001-512 through UP / DOWN buttons. Press SET UP button for confirmation of the setting.

Func

When disconnect the fixture from DMX controller, press MODE button into this window, then you can select the three modes:

Soun --- Sound active

2. Slav -----Mater / Slave mode

3. Auto----Auto run mode

Press SET UP button for confirmation of the setting.

Soun

Press MODE button into this window, then you can select 15 different flower effects from UP / DOWN buttons. Press SET UP button for confirmation of the setting.

P-00:

Program 1-15 flower effects run together

P-01>>P-15:

Program single flower effect

Sens

In Sound active mode, through this window you can adjust the sound sensitivity from:

S-00 >> S-15

Press SET UP button for confirmation of the setting.



Under this window, there are:

ON --- LED display on all the time

OFF ---LED display off after setting confirmed

Press SET UP button for confirmation of the setting.

Blnd

Under this window, there are:

ON --- Auto run mode when no sound active

OFF ---Blackout mode when no sound active

Press SET UP button for confirmation of the setting.

DMX Controlling Mode:

In Addr window, set the prefer DMX address for the following functions:

4CHANNEL:

CH I	CH2	CH3	CH 4
000-009	Static color selection (000-009:Blackout) (010-255:24static colors)	Strobe (000-255)	Dimmer (000-255)
10-255 (sound sensitivity)	000-015: Program1-15 016-255: Select single 1-15 effects	Strobe (000-255)	Dimmer (000-255)

Les 5 canaux DMX

Canaux	Valeurs	Spécifications	
1 : contrôle des fonctions	0-49	OFF	
	50-99	Variateur	
	100-149	Flash	
	150-199	Fondu	
	200-249	Son activé	
	250-255	ON	
2 : contrôle de vitesse	0-255	Réglage vitesse de lent à rapide	
3 : Rouge	0-255	Variateur de sombre à lumineux	
4 : Vert	0-255	Variateur de sombre à lumineux	
5 : Bleu	0-255	Variateur de sombre à lumineux	