

## WASH 150 XT DMX PROTOCOL 16 bit

Mode 1 Channel	Mode 2 Channel	Value	Function	Type of control
1	1	0-255	<b>Pan</b> Pan movement by 530°	proportional
2	3	0-255	<b>Tilt</b> Tilt movement by 280°	proportional
3	2	0-255	<b>Pan fine</b> Fine control of pan movement	proportional
4	4	0-255	<b>Tilt fine</b> Fine control of tilt movement	proportional
5	5	0 1-249 250-252 253-255	<b>Speed of PAN/TILT movement</b> Max. speed (tracking mode) From max. speed to min.speed (vector mode) Max. speed(track.mode),black-out while colour or gobo changes Max. speed(vector mode),black-out while PAN/TILT moving or colour or gobo changes	step proportional step step
6	6	0 10 21 32 42 53 64 74 85 96 106 117 128-189 190-193 194-255	<b>Colours</b> Open/white Turquoise Red Cyan Light green Magenta Light Blue Yellow Green Pink Blue Orange Forwards rainbow effect from fast to slow No rotation Backwards rainbow effect from slow to fast	proportional proportional proportional proportional proportional proportional proportional proportional proportional proportional proportional proportional proportional proportional proportional
7	7	0-255	<b>Dimmer intensity</b> Intensity from 0 to 100%	proportional
8	8	0 1-63 64-95 96-127 128-139 140-159 160-175 176-191 192-223 224-255	<b>Shutter,Strobe,Reset</b> Shutter closed Light intensity from 0 to 100% Shutter open Strobe-effect from slow to fast (max 8 flashes/s) Reset Shutter closed Pulse-effect in sequences with increasing speed Pulse-effect in sequences with decreasing speed Random strobe effect with increasing speed Shutter open	step proportional step proportional step step proportional proportional proportional step

## WASH 150 XT DMX PROTOCOL 8 bit

Mode 3 Channel	Mode 4 Channel	Value	Function	Type of control
1	1	0-255	<b>Pan</b> Pan movement by 530°	proportional
2	2	0-255	<b>Tilt</b> Tilt movement by 280°	proportional
3		0 1-249 250-252  253-255	<b>Speed of PAN/TILT movement</b> Max. speed (tracking mode) From max. speed to min.speed (vector mode) Max. speed(track.mode),black-out while colour or gobo changes Max. speed(vector mode),black-out while PAN/TILT moving or colour or gobo changes	step proportional step  step
4	3	0 10 21 32 42 53 64 74 85 96 106 117 128-189 190-193 194-255	<b>Colours</b> Open/white Turquoise Red Cyan Light green Magenta Light Blue Yellow Green Pink Blue Orange Forwards rainbow effect from fast to slow No rotation Backwards rainbow effect from slow to fast	proportional proportional proportional proportional proportional proportional proportional proportional proportional proportional proportional proportional proportional proportional proportional
5	4	0-255	<b>Dimmer intensity</b> Intensity from 0 to 100%	proportional
	5		<b>No function</b>	
6	6	0 1-63 64-95 96-127 128-139 140-159 160-175 176-191 192-223 224-255	<b>Shutter,Strobe,Reset</b> Shutter closed Light intensity from 0 to 100% Shutter open Strobe-effect from slow to fast (max 8 flashes/s) Reset Shutter closed Pulse-effect in sequences with increasing speed Pulse-effect in sequences with decreasing speed Random strobe effect with increasing speed Shutter open	step proportional step proportional step step proportional proportional proportional step